

1.14 Acrylic Primer Undercoat



DESCRIPTION

A general purpose water-based primer undercoat, suitable for interior and exterior bare timber surfaces. In addition to offering easy, low odour application, it is quick drying, enabling two or three coats to be applied in one day.

Recommended uses

Interior ✓ Exterior ✓

Type of substrate

Wood, plaster, concrete, cement rendering, brickwork and blockwork.

Colour range

White.

Finish

N/A

Volume solid

32%

Coverage

1 litre will cover approximately 13 square metres, depending on the nature and porosity of the surface. Under normal conditions, touch dry within 30 minutes, re-coatable after 1 to 2 hours.

Drying time

Touch dry in 30 minutes. Recoatable after 1-2 hours.

Transportation and storage

To avoid the risk of spillage, always store and transport in a secure upright position.
PROTECT FROM FROST.

Thinner

Clean water.

VOC content

MINIMAL VOC CONTENT 0-0.29%

VOCs (Volatile Organic Compounds) contribute to atmospheric pollution.

EU limit value for this product (Cat A/d): 150 g/l (2007) / 130 g/l (2010). This product contains max 3 g/l VOC.

Film thickness

Wet: 77µm
Dry: 24µm

Preparation

Ensure surface to be painted is sound, clean, dry and free from grease. Rub down bare timber surfaces with fine waterproof abrasive paper to remove raised grain and sharp edges. Apply Knotting Solution to knots and resinous surfaces. Rub down previously painted surfaces with fine waterproof abrasive paper to provide a key. Avoid the inhalation of dust. Wear a suitable face mask if dry sanding. Special precautions should be taken during surface preparation of pre-1960s paint surfaces over wood and metal as they may contain harmful lead. For further advice contact Technical Advisory.

Application

Stir well before use. Apply by brush or roller. Apply liberally, brushing firmly into the surface. Treat all accessible timber, in particular the end grain. A second coat serves as an excellent undercoat for Leyland Gloss Finish. Do not apply when the temperature is below 10°C or externally when rain is imminent.

Cleaning

Remove as much product as possible from application equipment before washing. Wash equipment immediately after use in warm soapy water and rinse thoroughly. Some local authorities have special facilities for disposal of waste coatings. Do not empty product into drains or watercourses. Replace lid firmly.

Precautions

PAINT PRODUCT

- Ensure good ventilation during application and drying.
- Avoid contact with skin and eyes.
- In case of contact with eyes, rinse immediately with plenty of clean water and seek medical advice.
- After contact with skin, wash immediately with plenty of soap and water or a recognised skin cleaner.
- Keep out of the reach of children.